



**T
H
E** **HAMMERHEAD-SKS**
SKS PIN-ON MAXIMUM EFFICIENCY MUZZLE BRAKE

INSTRUCTIONS:

1. Remove the factory pin on top of the barrel (front sight).
2. Install the brake; align the pin hole.
3. Use the supplied pin to affix the brake.
4. Use the set screws to center the brake on the barrel.

*We recommend using Red Loctite 263 on the set screws.